

Fleet

[Video Tutorial](#)



Registration	Aircraft Type	Model	Default Flight Number	MTOW	Capacity	Status	ACMI	Base	Price
111111	A320	A320	111111	175	180	Active		111111	199
222222	A320	A320	222222	175	180	Not Used		222222	199
333333	A320	A320	333333	175	180	Deleted		333333	199
444444	A320	A320	444444	175	180	Active		444444	199
555555	A320	A320	555555	175	180	Active		555555	199
666666	A320	A320	666666	175	180	Active		666666	199
777777	A320	A320	777777	175	180	Active		777777	199
888888	A320	A320	888888	175	180	Active		888888	199
999999	A320	A320	999999	175	180	Active		999999	199
101010	A320	A320	101010	175	180	Active		101010	199
111111	A320	A320	111111	175	180	Active		111111	199
121212	A320	A320	121212	175	180	Active		121212	199
131313	A320	A320	131313	175	180	Active		131313	199
141414	A320	A320	141414	175	180	Active		141414	199
151515	A320	A320	151515	175	180	Active		151515	199
161616	A320	A320	161616	175	180	Active		161616	199
171717	A320	A320	171717	175	180	Active		171717	199
181818	A320	A320	181818	175	180	Active		181818	199
191919	A320	A320	191919	175	180	Active		191919	199
202020	A320	A320	202020	175	180	Active		202020	199

Fleet - the general view on the list of aircraft

Managing the fleet in Leon is easy and handy. This section allows you to sort all essential information about aircraft in many ways. You can either display all types of aircraft or just one, you can hide tails that are not being used or view only ACMI aircraft.

Fleet main page shows details such as registration, type, serial number, default flight number (defined in aircraft profile), MTOW, capacity, status, ACMI, base and the price.

It the aircraft is marked as 'not used' or 'deleted' (in its profile), the status-dot is red. The same applies if the aircraft is excluded from billing (which is subject to Terms and Conditions and agreement with Leon Software Ltd.).

A column **Price** shows the price Leon charges based on an aircraft **MTOW**. There are 3 price compartments:

- 1. **MTOW 0 - 50 000 lbs** - 199 € per a tail.
- 2. **MTOW 50 000 - 110 000 lbs** - 329 € per a tail.
- 3. **MTOW > 110 000 lbs** - 449 € per a tail.

Aircraft edition

The aircraft edition panel is divided into **4** separate sections: **BASIC**, **OPS**, **SALES** and **PERFORMANCE**. Right below you can see an aircraft status: Active, Not Used or Deleted. Here you can also mark a checkbox **ACMI** if the tail is temporary leased or sub chartered aircraft by your company. Next to it you can see the price that Leon charges for the particular aircraft.

BASIC

Invalid Link
Aircraft basic information page

This page shows **basic** aircraft information and is split into a few sections, such as:

- 1. **AIRCRAFT TYPE** - mandatory data is: the aircraft Name, Short name, IATA code and the

aircraft registration. Additional data is: SELCAL (selective-calling number which can alert an aircraft's crew that a ground radio station wishes to communicate with the aircraft), aircraft phone number and Sat phone.

2. **CREW** - mandatory data is: minimum required Cockpit & Cabin crew, PAX capacity and Maximum Cargo. Additional data is: default Rest Facility (used for augmented and double crew flights).
3. **HOME BASE** - mandatory data is: Leon home base (select the base defined in General Setting for your operator) & ICAO home base. Additional data is: year of production & serial number.
4. **UNITS** - mandatory data is: MTOW (in a default unit defined in General Settings - Leon always shows suggested MTOW for a particular aircraft type). Additional data is: weight unit, fuel unit (also displayed in Journey Log for fuel inputs), Operator/ICAO code (Leon will show the operator name or a code on the Handling Requests form) and the Address.

OPS

This tab shows OPS related information of the aircraft, of which the mandatory ones are: **Max fuel & Burn fuel on taxi per h**.

The additional data is:

Aircraft category	Aircraft noise - all length	Maximum Takeoff weight
1	0 m up to but not including 9 m	20t
2	9 m up to but not including 12 m	25t
3	12 m up to but not including 18 m	30t
4	18 m up to but not including 24 m	40t
5	24 m up to but not including 28 m	45t
6	28 m up to but not including 39 m	55t
7	39 m up to but not including 49 m	65t
8	49 m up to but not including 61 m	75t
9	61 m up to but not including 76 m	85t
10	76 m up to but not including 90 m	95t

Aircraft 'Rescue & Fire fighting categories

- **Table view colour** - the aircraft colour in a section OPS > Table.
- **No handling needed at home base** - if marked, Leon will not require sending handling requests email.
- **Default flight type** - select N-non-scheduled, S-scheduled, G-general, X-other or M-military.
- **Default flight rule** - select IFR, VFR or other rules.
- **ICAO noise category** - the standard of the aircraft noise: Chapter 2, Chapter 3, Chapter 4, Chapter 10 or Chapter 14.
- **Rescue & fire fighting category** - an option to select the appropriate category depending on the aircraft length (see screenshot on the right).
- **Minimum runway length** - add the length in meters and if this value is greater than the airport's minimum length, Leon will a warning: 'The runway length is too short for this aircraft' in sections: OPS & Requests/Quotes.
- **Fuel type** - select fuel type used by the tail - it can be used for CO2 calculation displayed on Sales documents.
- **Max** - maximum block fuel for the tail (if the value in Journey Log's block fuel exceeds Max value, Leon shows a warning).
- **Burn on taxi (per h)** - average taxi fuel burn per hour.
- **Flight number** - default flight number displayed automatically in a section OPS when adding a new trip.
- **Increase by one** - if marked, adding a flight within one trip will by default increase the flight number by one (ABC1, ABC2, ABC3, ...) if the previous leg ends on any number.
- **Notes** - all information added into this field will appear on a Trip Sheet document.

SALES

In this panel you can add **Airport Fees & Aircraft Fees** (previously set up in a section SALES > FEES).

Aircraft Fees

H-LEON

Airport Fees

Medium Jet

Default commercial

Yes

UK APD Class

Standard

Pictures

EDIT PICTURES

Additionally you can select a default type for the trip in terms if it's **Commercial** or not. Also, you can define **UK APD Class** (between Reduced, Standard or Higher).

An interesting option is a possibility of uploading **pictures** for the particular aircraft and then make it displayed in your 'Requests/Quotes' panel documents with the help of [Documents Manager](#), where in Available Data > Aircraft you can find an item 'Pictures' to be used.

PERFORMANCE

Here you can add the **aircraft performance** data which will be used for calculating **STA** time on all trips on the particular tail.

Available field are: **Climb rate** (ft/min), **Descent rate** (ft/min), **Max Flight Level**, **Max range with '0' PAX** (NM), **Max range with max PAX** (NM) and **Minimum Ground Time** (when you add a new trip and the difference between STA of the last leg and STD of the new leg is less than 'Minimum Ground Time' set in this field, Leon will display a warning message. This value will also be used as a Rotation time for the aircraft and subsequently, towards Rotation prognosis calculation in the TIMELINE view.)

Below you can select which calculation **model** you want Leon to apply.

ADVANCED

The advanced calculation model can be useful on **short haul** flights, as it is more accurate if it comes to calculating STA.

Insert the **IFR Route Factor** (%) - here you can increase GCD (Great Circle Distance).

Calculation model

Advanced

IFR Route Factor*

1.00

%

DISTANCE PROFILES

Distance (NM)	Miles to Climb (NM)	Climb Time (hh:mm)	Cruise speed (kt)	
100	40	00:14	450	+ -
200	60	00:28	450	
300	80	00:42	450	

Save Cancel

Advanced aircraft performance settings

Define **DISTANCE PROFILES** - use + icon to add more entries.

- **Distance** [NM]
- **Miles to Climb** [NM]
- **Climb Time** [hh:mm]
- **Cruise speed** [kts]

If, for example, the Distance between ADEP & ADES is 400 NM, Leon will use distance profile added for 500 NM (as in the screenshot).

SIMPLE

Add the aircraft speed adding details into 'From' & 'Cruise speed' fields (just like in the old Fleet version), by defining speed per hour of the flight, i.e.:

00:00 275 (knots)

01:00 425 (knots)

Virtual Fleet

FLEET / VIRTUAL FLEET		
Aircraft Type <input type="text" value="Enter aircraft type name"/>		
Name	Aircraft Type	Capacity
VIRT 1	GLF4-0450	18
VIRT 2	GLF5-Gulfstream G550	16
CHALON VIRT	GLF4-0450	18
Records 1 - 3 from 3		

List of virtual aircraft in Fleet settings

The tab **VIRTUAL FLEET** allows creating a list of virtual aircraft, which are free of charge. There is no limit as to the number of aircraft available. Aircraft added here can be treated as regular tails and be used to plan the schedule ahead without creating the confirmed schedule. The process of creating the list is flexible and up the operator - the tails can be copies of the actual fleet or any types that suit the company policy.

In order to add a new aircraft click

NEW AIRCRAFT

 and fill out the form.



Virtual aircraft in Calendar view

Once added to the list the aircraft will be visible in all views (Table, Calendar & Timeline) of the OPS panel. The order of displaying the aircraft can be set using the option AIRCRAFT in any of the schedule views, where Active (+Virtual) or All has to be selected in the filter in order to view the virtual aircraft. The order is set up by dragging and dropping the tail in the list.

The virtual tails can be used just like the regular tails in order to plan the schedule in a panel [SCH](#)ED

which is the functionality allowing you to build and manage the schedules. Functionality is designed with Airlines in mind. However, it still can be used by business and charter operators to build schedules if need be.

From:

<https://wiki.leonsoftware.com/> - **Leonsoftware Wiki**

Permanent link:

<https://wiki.leonsoftware.com/leon/fleet-setup?rev=1581076590>

Last update: **2020/02/07 11:56**

