


Functions




Adding crew functions to fleet

Once [aircraft are added](#) to Leon you need to add appropriate **functions** (crew positions) to it. It is very important part of the system because it will allow you to add [ratings](#), [assign crew to flights](#) and [create duty on aircraft](#).

In this section select an aircraft type in the filter and mark needed checkboxes.

You can see 5 columns in this section:

- **Use / Function / Default** - If you want to use added **function** every time you add a new flight (i.e. CPT and FO) mark checkboxes in both columns: **Use** and **Default**. If some added functions should remain hidden in the [Editing flight](#) page, just leave column 'Use' marked. To use it, when it's necessary, click on the icon  in the 'Edit Flight' section.
- **Wage** - basic way of calculating wages
- **Notes** - basic information regarding function i.e. notes next to **FO** could be 'Copilot'. Notes remain in this section are NOT displayed anywhere else in Leon.

You can assign function to each part of your business (Flying crew, Maintenance, Ground) by going to different tabs in the top of the screen.

Positioning tab will allow you to assign functions that do not calculate FDP but duty only (PSN) or neither FDP nor Duty (PAD).

From:
<https://wiki.leonsoftware.com/> - **Leonsoftware Wiki**

Permanent link:
<https://wiki.leonsoftware.com/leon/functions>

Last update: **2016/08/30 13:06**

